



Features and Benefits



3M™ Scott™ Air-Pak™ X3 Pro SCBA

NFPA 1981/1982, 2018 Edition

| Features | Benefits |
|---------------------------------|---|
| As Long As You Own It Warranty | Gain peace of mind knowing that your most important investment is backed for the lifetime ownership of the product |
| New Harness Materials | Offers greater resistance to chemical exposure and less water absorption, helping to minimize contamination; Provides improved durability to withstand the rigors of the fireground; Improves SCBA ergonomics to help reduce user fatigue and enhance comfort |
| Removable Harness | Easy-to-remove harness allows for cleaning to help with exposure reduction efforts, while also improving serviceability |
| New Shoulder Harness | Improves the ease of donning the SCBA and minimizes pressure points to help reduce user fatigue and improve comfort |
| Natural Articulation | Promotes greater range of motion to the firefighter, while transferring weight to the hips for a more balanced load; Minimizes wear and tear commonly found with mechanical articulation |
| New E-Z Flo C5 Regulator Design | Offers enhanced performance with lower breathing resistance, helping to reduce user burden and improve operational efficiencies |
| Redundant Safety Features | Affords firefighters peace of mind knowing that the SCBA will perform in critical life safety environments; Provides reliability and performance to ensure the safety of firefighters |
| New Buckle Design | Provides firm hold to prevent inadvertent loosening of shoulder and waist straps, to help provide a secure fit of SCBA on the firefighter |
| Bluetooth® Enabled Electronics | Supports wireless connectivity between devices for improved configurability, data transmission/retrieval, firefighter safety and fireground accountability |
| Electronic PAR (ePAR) | Provides wireless, bi-directional communication between the firefighter and incident command (using Monitor Pro telemetry software) to improve fireground accountability and communications |
| System Integrity Alarm | Visual and audible alert to notify SCBA wearer and incident command (using Monitor Pro telemetry software) of impending electronics degradation due to elevated temperature |

| Features | Benefits |
|-------------------------------------|---|
| High Flow Alarm | Visual and audible alert to notify incident command (using Monitor Pro telemetry software) of a high flow condition from a firefighter's SCBA during a full-alarm PASS activation (i.e. heavy breathing, free flow, etc.) |
| No Flow Alarm | Visual and audible alert to notify incident command (using Monitor Pro telemetry software) of a no flow condition from a firefighter's SCBA during a full-alarm PASS activation |
| Integrated RFID Tags | Provides local storage of SCBA information that can be wirelessly interrogated for asset tracking |
| 3M™ Scotchlite™ Reflective Material | Enhances visibility of the SCBA harness and webbing when operating in low light conditions, improving safety and accountability on the fireground |
| "Buddy" Lights | Optimally positioned on the backframe to enable a 360° view of the firefighter's air pressure and PASS status |
| Integrated Drag Rescue Loop | Sewn into SCBA harness and attached to backframe, providing a horizontal pull strength of 1000 lbs to assist with rescuing a downed firefighter |
| Aluminum Alloy Backframe | Lightweight, durable design to withstand the rigors of the fireground |

DASTEC S.R.L.

Representantes / Distribuidores Autorizados

Argentina

Tel: (+54 11) 5352 2500

Email: info@dastecsrl.com.ar

Web: www.dastecsrl.com.ar



3M Scott Fire & Safety

Personal Safety Division
Monroe Center, P.O. Box 569
Monroe, NC 28111

Phone 1-800-247-7257
Email US-3M-ScottMonroeCSR@mmm.com
Web 3MScott.com

H/S 7617 RevF_EN 07/20 ISO 9001 Registered.
Please recycle. Printed in USA © 3M 2020. All rights reserved.
3M and Scott are trademarks of 3M.