

SENTRY ISOLOK SAH SAMPLER

Point Samplers

AUTOMATIC SAMPLING

The Sentry® ISOLOK® SAH automatic point sampler is an extended stroke sampler for collecting flowable free-falling materials within chutes or slides. A three-inch plunger stroke collects samples inside heavy-body or double-wall vessels such as mixers, dryers and reactors. An air cylinder extends a single plunger into the process material, then immediately withdraws, carrying a fixed amount of sample trapped in an annular ring between plunger seals. Process or flow ports are always closed, preventing leaks or product loss. There are no tubes or passages to become clogged. The gravity-discharged sample is transferred directly to a closed container.

MODELS

ISOLOK SAH

BENEFITS

The Sentry ISOLOK SAH sampler seal design isolates the operator from the process at all times, with the sample captured in the container "locked out" from external influences.

The samplers can be used for composite, batch or analysis sampling techniques. Composite sampling is accomplished by obtaining a series of precisely measured material samples at set intervals or adjusted in response to product flow. Samples can be collected in shared or individual containers. Batch or analysis sampling in response to immediate need or on-line process control interface is facilitated using single or rapid-cycling material withdrawal.

A complete line of programmable automatic sampler controllers is available for use in general purpose as well as hazardous environments.

FEATURES

- Collects samples from slide or vertical drop chutes or direct from open processes
- Single moving part collects accurate and repeatable 40 or 50 cc sample volume
- Simple gravity-discharge design for powder, flakes or pellets up to 5/8 inch (16 mm) without shearing or degrading sample material
- Rugged 316 stainless steel construction features chrome-hardened body bore


- Field-replaceable, application-specific seals include EPDM, polyurethane elastomers and more
- Extended-stroke plunger ideal for sample collection inside heavy-body/ double-wall vessels
- Clamp ferrule for easy installation and maintenance
- ATEX-compliant models available







SENTRY ISOLOK SAH SAMPLER > POINT SAMPLERS > AUTOMATIC SAMPLING



| SPECIFICATIONS | |
|-------------------------------------|----------------------------------------------------------------------------|
| sample volume per cycle | 40 or 50 cc |
| maximum particle size | 0.62 in (16 mm) |
| maximum cycle frequency | 12 strokes per minute, depending on application |
| materials | 316 stainless steel; other materials available |
| actuator seals | filled Teflon®; other materials available |
| static seals | fluoroelastomer; other materials available |
| plunger seals | filled Teflon, polyurethane, EPDM rubber; other materials available |
| sample temperature range | -40°F to 575°F (-40°C to 302°C), depending on seal material and duty cycle |
| ambient operating temperature range | -5° to 131°F (-20° to 55°C) depending on seal material |
| line mount adapter type | 2.5 in (63 mm) clamp ferrule |
| compressed air requirement | 2 SCFM at 30 to 80 psig (2.1 to 5.5 barg) |
| dimensions | 14.7 in x 3 in (373 mm x 76 mm) |
| shipping weight | 21 lb (9.5 kg) |

Teflon is a registered trademark of E. I. Du Pont de Nemours and Company.



Representantes / Distribuidores Exclusivos

Argentina

Tel: (+54 11) 5352 2500 Email: info@dastecsrl.com.ar Web: www.dastecsrl.com.ar

Uruguay www.dastecsrl.com.uy

Paraguay www.dastecsrl.com.py

Bolivia www.tecdas.com.bo



COMPANY WITH QUALITY SYSTEM CERTIFIED BY DNV GL = ISO 9001 =